

38 SB SILVERTON
BIMINI AND ENCLOSURE
PACKING LIST

<u>BIMINI AND ENCLOSURE:</u>	<u>P/N</u>
30 Glove Button 7/8in windshield clips	10391
30 Glove Button Caps (Color)	10128(B,W,T)
30 Glove Button Sockets	10224
32 LTD 3/8 Screw studs	16360
2pcs Flex Rail track 56in (attached to frame)	T5
36 Flex Rail Screws	FRSC



38 SB Silverton Bimini and Enclosure Instructions

1. Release the quick pins on the front struts to make zipping the top on easier. Make sure center of top is on center of the frame. Use center mark of frame for reference. Pull the top taught and attach the front struts.



2. Track for the enclosure is packed with the frame. Install the flex track inside the arch as shown in this picture. Start outside the main and work to the back so that the track follows the inside edge of the bridge. Install the flex rail screws provided about every 4in.



3. Bend the track at the back of the arch and in front of the rail stanchion so any water will be shed over board. Repeat on the opposite side.



38 SB Silverton

4. After the top and track have been installed zip all the enclosure panels in place. Zip all the panels together and check the enclosure for general fit and finish.



5. Begin with the front curtains. The buttons have not been installed in the panels to allow for adjustment on each boat. Use reference marks on each curtain to locate the windshield clips on the frame. Working from the center out to each side mark and install buttons one at a time.



6. Install back curtains by lining the center zipper with the anchor light. Work out to each side installing the lift the dot studs provided.



38 SB Silverton

7. Unzip the rope from the side curtain and slide it into the track. You may have to unzip the top of the panel partially to get the bottom started. Once that is done close both zippers completely.



8. After the front and back are complete finish the install with the sides. Use the lift the dot studs provided until all the fasteners are installed.