

**45C SILVERTON**  
**WINDSHIELD COVER**  
**PACKING LIST**

**Hardware**

\_\_\_\_ 16pc Glove button screw studs

\_\_\_\_ 3pc Lift the dot studs



Drape the windshield cover across the windshield aligning the seams in the cover with the seams in the windshield. Install the center button on the center of the windshield about 1" down from the glass. Next install one button at each bottom corner. Using the glove button studs provided. Next, "unsnap" the center button to allow proper placement of the top corners.



Next install the lift the dot stud up under the bridge overhang. Pull the cover around the corner as tight as possible and mark the center of the button. Install the button 1/4" aft of the button to ensure a snug fit. Pull the back corners down and back, mark and install the remaining studs. Repeat on the opposite side.

